

**⚡ OPERATING & CHARGING PROCEDURE**

Press power switch can turn on the light and activate the battery indicators, 4 pcs LED located the back of the light. The 4 pcs LED indicate the battery capacity. From left to right, 1 pc, 2 pcs, 3 pcs, 4 pcs led are lighted to indicate respectively 25%, 50%, 75%, 100% volume of battery until turning off the light. When battery capacity is low, the light which is turned on will flash 3 times.

2645-LMF001-001 Operating mode as below

1. Press the power Switch first time, Top light will switch on.
2. Press the power Switch second time, Main light switches to ECO power mode.
3. Press the power Switch third time, Main light switches to Normal mode.

4. Press the power Switch fourth time, Main light switches to Full power mode.

5. Press the power Switch fifth time, whole lights switch off.

LMF001-001 Dimmer mode as below

1. Stepless dimmer function is between the range of 10% to 100%

2. Press and hold the power button while main light is on to start dimming or increasing.

3. Lowest and highest levels are indicated by flashing of the light.

Switch lamp off and connect with USB charger during charging.

The battery indicator will blink during charging.

All the battery indicator will stay lighting up after finished the charging.

If the battery indicator did not light up, please remove the charger and try again.

Always only use the charger recommended to charge the lamp. The use of a NON-recommended charger can lead to a fire and destroy the lamp.

Before taking the hand lamp into service for the first time charge it for 4-5 hours.

Fully charge the hand lamp before it is stored for a longer period.

**⚠ WARNING!**

Do not open the device.

Do not look directly into the light emitting lamp.

Risk of eye injuries!

Do not operate in direct sun light or extreme temperature conditions.

Operating temperature, -10°C to +40°C.

Keep away from children! Children should be supervised in order to ensure that they do not play with the device!

**SAFETY INSTRUCTIONS**

Do not use the device if there is damage to the housing, plug or cable. Consult your local authorized specialist!

Do not open the device! Repair work and replacing the rechargeable battery pack may only be carried out by electricians.

Carry out cleaning tasks only when the mains plug is removed from the mains power!

There is a risk of short-circuit. Repairs on the device may only be carried out by commissioned and trained persons.

Please contact your nearest authorized branch.

Protect the battery against heat, e.g., against continuous intense sunlight, fire, water, and moisture. Danger of explosion. If the battery is damaged or not used correctly. Fluids can leak from the battery. Avoid contact with these. Leaking battery fluids can lead to skin irritation or burns. Rinse off with water if you should come into contact. If the fluid gets into your eyes, make sure you get medical help.

The lamp is not allowed to be placed on the light surface while being switched on.

**♻ ENVIRONMENTAL PROTECTION**

The device should not be discarded in the normal household waste under any circumstances.

Dispose of the device via an authorized disposal center or your communal waste disposal facility.

Observe the current applicable regulations.

Contact your waste disposal facility in the event of any doubt. Dispose of all packaging materials via an environmentally friendly disposal facility.

Rechargeable batteries must not be disposed of in the household waste.

Return used rechargeable batteries to your dealer or hand them in to a battery collection facility.

**WARRANTY**

The guarantee does not apply to damage to the device arising through a failure to comply with the operating instructions. Subject to technical changes.

We assume no liability for printing errors.

TECHNICAL DATA	
Light Source	High Power COB LED-Main Light High Power SMD LED-Top Light
Luminous Power	1000 lm - Main Light Full Power Mode 500 lm - Main Light Normal Mode 250 lm - Main Light ECO Mode 150 lm - Top Light
Operating Time	2H - Main Light Full Power Mode 4H - Main Light Normal Mode 8H - Main Light ECO Mode 7H - Top Light
Battery Specification	Li-Ion 3.7V, 2600mAh, 9.62Wh
Charging Time	3.5h
Charging Input	DC 5V 1A
Degree of Protection	IP65, IK07
Operating Temperature	-10°C to +40°C