

⚡ OPERATING & CHARGING PROCEDURE

1. Plug DC 5v 2A Adapter into the type c input of Wireless Charging Dock 2645-LMZ001.
2. The Red Led indicator near the type-c input will flash 3 times then turn off to indicate the charging dock is ok for charging lamp.
3. Switch a wireless charging lamp off and put it on the dock, the magnetic force will attract the lamp directly to the proper position of charging dock. The red led indicator will light again to indicate the dock is at the charging status.
4. During the charging, the led indicators of lamp will flash and indicate the charging power of battery.
5. All the battery indicator of lamp will stay lighting up after finished the charging.
6. If the battery indicators of lamp do not light up or the led indicator of the dock flashes, please remove the lamp from the dock and try again.

⚠ WARNING!

Always only use the wireless charging dock to charge the Lumax's wireless charging lamps. The use of a NON-recommended lamp might lead to a fire and destroy the lamp.

Do not open the device.

Do not look directly into the light emitting lamp - Risk of eye injuries!

Do not operate in direct sunlight or extreme temperature conditions.

Operating temperature, -10°C to +40°C.

Keep away from children! Children should be supervised in order to ensure that they do not play with the device

TECHNICAL DATA	
Input Power	DC 5V 2A
Wireless Charging Power	Max10w
USB Output	DC 5V 2A
Degree of Protection	IK07
Operating Temperature	-10°Cto+40°C

SAFETY INSTRUCTIONS

Do not use the device if there is damage to the housing, plug or cable. Consult your local authorized specialist!

Do not open the device! Repair work and replacing the rechargeable battery pack may only be carried out by electricians.

Carry out cleaning tasks only when the mains plug is removed from the mains power!

There is a risk of short-circuit .Repairs on the device may only be carried out by commissioned and trained persons. Please contact your nearest authorized branch.

Protect the battery against heat, e.g., against continuous intense sunlight, fire, water, and moisture. Danger of explosion.

If the battery is damaged or not used correctly. Fluids can leak from the battery. Avoid contact with these. Leaking battery fluids can lead to skin irritation or burns. Rinse off with water if you should come into contact. If the fluid gets into your eyes, make sure you get medical help.

The lamp is not allowed to be placed on the light surface while being switched on.

♻ ENVIRONMENTAL PROTECTION

The device should not be discarded in the normal household waste under any circumstances.

Dispose of the device via an authorized disposal center or your communal waste disposal facility.

Observe the current applicable regulations.

Contact your waste disposal facility in the event of any doubt.

Dispose of all packaging materials via an environmentally friendly disposal facility.

Rechargeable batteries must not be disposed of in the household waste.

Return used rechargeable batteries to your dealer or hand them in to a battery collection facility.

WARRANTY

The guarantee does not apply to damage to the device arising through a failure to comply with the operating instructions.

Subject to technical changes .

We assume no liability for printing errors.